



# 250 Generation 3

## SINGLE DISC DIAMOND GRINDER

### METEOR 250 G3 PRE START

- Check the inlet lead and plug
- Check overload on the bottom of the handle electrical box
- Check emergency stop
- Check blade mount is firm with no free play
- Dust port clear
- Check oil damper operation

### METEOR 250 G3 OPERATION

- Folding handle operation
- Axle edging operation
- Check machine is stable and level
- Grind in straight lines
- Always start and stop with the disc on the ground
- Always operate with wheels on the floor



### METEOR 250 G3 DEHIRE

- Spanner
- Edger shroud
- Measure diamond wear
- Check for damage
- Check blade mount

### METEOR 250 G3 ELECTRICAL

- Extension lead - 2.5mm<sup>2</sup> max 20m - 4mm<sup>2</sup> max 50m
- Voltage - not running 230-240v - operating load 220v+
- Amps - no load 4-5A - operating load 9-10A



SCAN HERE TO GO TO THE VIDEO



**FLOOREX<sup>®</sup>**  
**PRODUCTS**

**Australia-Wide - 1800 356 673**

**www.floorex.com.au**